


Weber Smokey Mountain Parts Schematics for 22.5 inch Smokers

Weber Smokey Mountain Model Number 731001

<http://www.WeberReplacementParts.com>



3

1 63016 Damper kit, 22.5" Bar-B-Kettle & Smokey Mountain Cooker

2 63004 Lid assembly, 22.5" Smokey Mountain Cooker, black, '09

<u>3</u>	80630	Cooking grate, 22.5", '10
<u>4</u>	85041	Lower cooking grate, 22.5" SMC '14
<u>5</u>	63021	Grill straps set, 22.5" Smokey Mountain Cooker
<u>6</u>	63008	Charcoal chamber, 22.5" Smokey Mountain Cooker, black, '09
<u>7</u>	63014	Charcoal grate, 22.5" Smokey Mountain Cooker, '09
<u>8</u>	80671	Handle kit, charcoal, qty 1, '10
<u>9</u>	63026	Bezel for thermometer, 22.5" Smokey Mountain Cooker, '09
<u>9</u>	63029	Thermometer, 22.5" Smokey Mountain Cooker
<u>10</u>	63025	Water pan, 22.5" Smokey Mountain Cooker, '09
<u>11</u>	63030	Center ring, 22.5" Smokey Mountain Cooker, black, '09
<u>11</u>	85040	Center ring, 22.5" Smokey Mountain Cooker, black, '14
<u>12</u>	85037	Grommet, gray, SMC '14
<u>13</u>	63019	Door assembly, 22.5" Smokey Mountain Cooker, '09
<u>14</u>	63006	Bowl for 22.5" Smokey Mountain Cooker, black, '09
<u>15</u>	63017	Heat shield, 18.5"/22.5" Smokey Mountain Cooker, '09

16 63023 Leg kit, 22.5" Smokey
Mountain Cooker, '09